

SnowEx U-SET (User Settings) FEATURE

This feature allows the user to customize features on this control to their own preferences. Customizable features include:

***Soft Stop *Quick Float *Double Tap *Down Pressure *Reverse Up/Down *Factory Reset**

Disclaimer: 906 Engineering is NOT responsible for any damage or injury caused by the use of these customizable features. Read all instructions and make sure you understand how these settings will affect the behavior of the plow. Unintended plow motion can be a hazard to other drivers.

To enter Programming Mode:

1. Turn the control OFF.
2. PRESS and HOLD the "DOWN" button, then PRESS & RELEASE the ON/OFF button (Solid Blue).
3. RELEASE the "DOWN" button. The indicator light at the top of the keypad flashes BLUE.

(You are now in programming mode and the control will not operate the plow)

You can only change one setting at a time, now choose the feature U would like to SET.

***Soft Stop (Turn ON or OFF) - Factory setting is ON**



WARNING

Turning OFF the Soft Stop feature could cause damage to your plow's hydraulic system and may shorten the life of valves and hoses.

4. Hit the RIGHT button once (GREEN), hit the RIGHT button again (RED). Continuing to hit the RIGHT button will toggle between GREEN & RED. Now, choose the setting you want (**GREEN = ON, RED = OFF**) and go to step 5.

***Quick Float or One Touch Float (Turn ON or OFF) - Factory setting is OFF**



WARNING

When Quick Float is turned ON, the plow will immediately drop into FLOAT with one touch of the DOWN button. When using Quick Float, it is recommended that you raise the plow and turn your control OFF (to avoid accidental activation of Float) when driving on the road.

4. Hit the LEFT button once (GREEN), hit the LEFT button again (RED). Continuing to hit the LEFT button will toggle between GREEN & RED. Now, choose the setting you want (**GREEN = OFF, RED = ON**) and go to step 5.

***Double Tap Up & Float (Turn ON or OFF) - Factory setting is OFF**

4. Hit the UP button once (flash GREEN). Then, hit the RIGHT button once (GREEN), hit the RIGHT button again (RED). Continuing to hit the RIGHT button will toggle between GREEN & RED. Now, choose the setting you want (**GREEN = OFF, RED = ON**) and go to step 5.



WARNING

When Double Tap is turned ON, the plow will immediately drop into FLOAT with a Double Tap of the DOWN button. When using Double Tap, it is recommended that you raise the plow and turn your control OFF (to avoid accidental activation of Float) when driving on the road.

***Down Pressure (Turn ON or Off) - Factory setting is OFF**

4. Hit the UP button once (flash GREEN). Then, hit the LEFT button once (GREEN), hit the LEFT button again (RED). Continuing to hit the LEFT button will toggle between GREEN & RED. Now, choose the setting you want (**GREEN = OFF., RED = ON**) and go to step 5.



WARNING

DO NOT turn the Down Pressure Feature ON until the SnowEx Pressure Switch has been installed. If you do, YOU COULD DAMAGE YOUR SNOW PLOW.

***Reverse Up/Down (Changes keypad to UP = lower plow & DOWN = Raise plow)**

4. Steadily PRESS the DOWN button 6 TIMES (until indicator light flashes RED to BLUE). Then, hit the RIGHT button once (GREEN), hit the RIGHT button again (RED). Continuing to hit the RIGHT button will toggle between GREEN & RED. Now, choose the setting you want (**GREEN = Normal UP/DOWN, RED = Reverse UP/DOWN**) and go to step 5.

***Factory Reset (Changes all U-Set Features back to Factory Settings)**

4. Steadily PRESS the DOWN button 6 TIMES (until indicator light flashes RED to BLUE). Then, hit the LEFT button once (GREEN), hit the LEFT button again (RED). Continuing to hit the LEFT button will toggle between GREEN & RED. Now, choose the setting you want (**GREEN = Keeps Current Settings, RED = Resets Control to Factory Settings**) and go to step 5.

To Exit Programming Mode:

5. Once the indicator light is set correctly (GREEN or RED), PRESS the "UP" button one time. The indicator light will flash BLUE to GREEN and your chosen setting is now programmed.
6. PRESS the "DOWN" button to exit programming mode. The control will automatically turn OFF.
7. Turn the control back ON and test it to ensure proper changes were made.

Changes will remain on control until it is reprogrammed back to the original settings